

Comparison Chart for Drill Size & Stainless Sleeves and Inserts

The chart below provides an example of possibilities for which Guide Sleeve Insert to use depending on the drill size and guide sleeve size. To insure proper fit with the guide sleeves and inserts, measure the actual outside diameter (od) of the drill you are using. Order the next size larger guide sleeve or insert.

Example: If the drill od is 2.25 mm, order 2.5 mm insert for the 4.5 mm guide sleeve. The recommended clearance between drill and sleeve should be greater than or equal to 0.1 mm.

REMEMBER, TIGHT DRILLS GENERATE HEAT.

Our Template Components are universal and compatible with, but not limited to, the following implant company drills:

- 3I
- Anklos
- Astra
- Bicon
- Bio-Horizons
- Lifecore
- Mega-Gen
- Nobel
- Straumann
- Thommen
- XiVE
- Zimmer

Drill Chart Key:

